



1/2" ProPanel™

Lightweight Waterproof Backer Board For Walls, Tubs & Ceilings

WALL/CEILING INSTALLATION

Option 1:

1. Attach to wall studs using appropriate fasteners every 8" o.c.
2. Apply a 1/4" bead of sealant to top edge of first board.
3. Install next board and apply fasteners.
4. Whenever two boards come together to make a joint apply a 1/4" bead of sealant.
5. Boards must be fitted tightly together allowing sealant to ooze at the joint.
6. Excess sealant should be spread thin creating a continuous seal at the joint.
7. Fasteners must be completely covered with a bead of sealant and spread to form a seal.

Option 2:

1. Fasten boards per OPTION 1 without the use of sealant.
2. Install boards leaving a 1/16" gap between boards.
3. Embed 2" fiberglass mesh with liquid water proofing membrane in all joints.
4. Fasteners must be completely covered with waterproofing to form a seal.
5. Allow 1st coat to dry and apply 2nd coat.

1/4" ProPanel is approved for floor installations.