



COUNTERTOPS: ¼”ProPanel

Wood Counter: Install ¾” exterior grade plywood across unit supports spaced 16” o.c. Maximum variation in plywood surface to be no more than 1/8” in 10’ from required plane.

FASTENING:

Fasten ProPanel to plywood using either ProPanel 1 ½” Assembled Cap Nail or ProPanel 1 ¼” Tab Washer and 1 5/8” Corrosion Resistant Screw. Fasteners should be spaced 8” o.c. All fastener heads should be countersunk flush with surface of the board.

INSTALLATION:

The following steps must be followed to maintain the waterproof integrity of ProPanel.

1. Fasten ProPanel to plywood as outlined in FASTENING section.
2. Before installing the next board, apply a ¼” bead of polyurethane sealant to the edges of the first board.
3. Install next board and apply fasteners as outlined above.
4. All boards must be fitted tightly together allowing sealant to ooze from joint.
5. All excess sealant should be spread thin ensuring a continuous seal at the joint.
6. All fasteners must be completely covered with a bead of polyurethane and spread to form a seal.